



Remote Controller

YK-H




- 1 Clean Function
- 2 Mode Setting AUTO/COOL/DRY/HEAT/FAN
- 3 Sleep Function
- 4 Up and down wind
- 5 No Function
- 6 Anti-fungus Function
- 7 ON/OFF
- 8 Fan Speed Setting HIGH/MED/LOW/AUTO
- 9 Strong Wind
- 10 I IF Feele Flu Fnuctnionctn
- 11 T iTmimere Or nO/Onf/fOff
- 12 ELDE Di sDpliasyp Olany/ Offn/Off
- 13 Heaeltahlt Fhu Fnuctnionctn

YK-K




- 1 Mode Setting AUTO/COOL/DRY/HEAT/FAN
- 2 Fan Speed Setting HIGH/MED/LOW/AUTO
- 3 Vertical Swing
- 4 Lock
- 5 Electrical Heating
- 6 Sleep Function
- 7 LED Display On/Off
- 8 Temperature-Setting /Timer Range Setting
- 9 ON/OFF
- 10 T iTmimere Or nO/Onf/fOff
- 11 H Horozroiznotanlt Sawl iSnwging
- 12 Clealena Fnu nFcutnionctn
- 13 Heaeltahlt
- 14 F uFnugnugspursoporfo Foufn Fctuiionctn

YK-T



- 1 ON/OFF
- 2 Mode Setting AUTO/ COOL/ DRY/ HEAT/ FAN
- 3 Time On/Off
- 4 Heating Mode
- 5 Cooling Mode
- 6 Fan Speed Setting Low/Mid/High/Turbo/Auto
- 7 Temperature-Setting /Timer Range Setting
- 8 MENU & OK Button
- 9 L/R SWING Button
- 10 U/D SWING Button


YK-L



- 1 ON/OFF
- 2 Fan Speed Setting
- 3 Temperature-Setting
- 4 Cooling Mode
- 5 Heating Mode
- 6 Vertical Swing/Horizontal Swing
- 7 Mode Setting
- 8 Turbo Wind
- 9 Health Function
- 10 Silence Function
- 11 Sleep Function
- 12 Timer On/Off
- 13 I Feel Function
- 14 LED Display On/Off
- 15 Anti-fungus Function
- 16 Clean Function
- 17 Auxiliary Electric
- 18 Spot Swing
- 19 Economic Function


Wired Controller

XK-04 (86x86mm)




- 1 Remote Signal Receiver
- 2 Photosensitive Sensor Receiver
- 3 Fan Button
- 4 Timer Button
- 5 Function Button
- 6 "+" Button
- 7 "-" Button
- 8 Swing Button
- 9 Mode Button
- 10 ON/OFF Button

XK-05 (120x120mm)



- 1 Remote Signal Receiver
- 2 Timer Button
- 3 Fan Button
- 4 Function Button
- 5 "+" Button
- 6 "-" Button
- 7 Photosensitive Sensor Receiver
- 8 Mode Button
- 9 Swing Button
- 10 ON/OFF Button

XK-06 (120x120mm)



- 1 Indicator light
- 2 MENU/OK Key
- 3 Up Key
- 4 FAN/Left Key
- 5 Down Key
- 6 SWING/Right Key
- 7 Active Area
- 8 BACK Key
- 9 MODE Key
- 10 ON/OFF Key